


JVC

Chassis V52

SERVICE MANUAL

MODEL TK-870E



CONTENTS

- INTRODUCTION AND REPAIR SERVICE
- ADJUSTMENT
- PARTS LIST
- STANDARD CIRCUIT DIAGRAM

(NOTE) Electrical components having special safety-related characteristics are identified by shading (■) on the schematic and by (Δ) on the parts list in Service Manual. When replacing these components, be sure to use designated parts.

SPECIFICATIONS

| Item | Content | Item | Content |
|------------------------------|---|---------------------------------|---|
| Type | Colour video camera head | Minimum object illumination | 20 Lux (F1.4 lens, AGC operational) |
| Colour system | PAL standard | Recommended object illumination | 2,000 Lux |
| Pickup element | 2/3" solid-state CCD (Charge Coupled Device) | White balance setting | Indoor (approx. 3,200K)/Outdoor (approx. 5,500K), switchable |
| Effective pixels | 500H × 582V | Lens mount | C-mount |
| Scanning | 625 lines, 2 : 1 interlaced | Power requirement | DC 12V (± 10%) |
| Synchronizing system | Internal/external Automatic switching | Power consumption | 6.7 VA |
| Sync reference signal input | Composite video signal (VBS)/1.0 Vp-p, 75 ohms, terminated (or black burst signal (B.B.)) Connector: BNC | Operating temperature range | -5 to +40°C (23 to 104°F) |
| Sync reference signal output | Composite sync reference signal/approx. 0.3 Vp-p, 75 ohms, unbalanced Socket: D-sub 9-pin | Operating humidity | Less than 90% (without moisture condensation) |
| Video signal output | Composite video signal/1.0Vp-p, 75 ohms, unbalanced (2 outputs: BNC, connector/D-sub 9-pin socket) R.G.B video signal/0.7 Vp-p, 75 ohms, unbalanced (1 output: D-sub 9-pin socket) | Fuse | QMF51E2 - 1ROS (1A) × 1 QME51E2 - R40S (0.4A) × 1 |
| Video S/N ratio | 45 dB | Dimensions (W × H × D) | 88 × 85 × 158 mm, (3-1/2" × 3-3/8" × 6-1/4"), without dust cap |
| Resolution | 320 TV lines (horizontal) | Weight | About 860g (1.9 lbs.), without dust cap |
| | | Provided accessories | Dust cap × 1 Power cord × 1 Iris plug (for iris socket) × 1 |

* Design and specifications are subject to change without notice.

CONTENTS

1. INTRODUCTION AND REPAIR SERVICE

| | |
|--|---------|
| OPERATING INSTRUCTIONS | 3 ~ 6 |
| SPECIFIC SERVICE INSTRUCTIONS & PRECAUTIONS | 7 ~ 13 |
| ■ SPECIFIC SERVICE ITEMS & PRECAUTIONS | 7, 8 |
| ■ TWO-SIDE HOLE-THROUGH PCB | 9 |
| ■ REPAIRING CIRCUIT BOARD MODULES | 9 |
| ■ REPLACING CHIP COMPONENTS | 9 |
| ■ CHIP COMPONENTS DISPLAY | 9, 10 |
| "CHARGE COUPLED DEVICE (CCD)" IMAGER | 11 ~ 13 |
| ■ SPECIAL CHARACTERISTICS OF A CCD | 14 |
| REMOVING CASINGS, COVERS & OTHER COMPONENTS | 15 ~ 17 |

2. ADJUSTMENT

| | |
|---|---------|
| MEASURING INSTRUMENTS, TOOLS AND FIXTURES FOR ADJUSTMENT | 18 |
| INSTRUMENT CONNECTION AND SET UP | 19 |
| PRIOR TO STARTING ADJUSTMENT | 20 |
| ADJUSTMENT PROCEDURES | 20 |
| MAIN PARTS ARRANGEMENT AND LOCATIONS OF BOARDS | 21 |
| ADJUSTING STEP | 22 |
| ADJUSTMENT LOCATIONS | 23, 24 |
| ● PRESETTING | 25 |
| 1. ADJUSTMENT OF THE POWER | 25 |
| 2. ADJUSTMENT OF THE SSG | 26 |
| 3. ADJUSTMENT OF THE SIGNAL SYSTEM | 26 ~ 39 |
| 4. ADJUSTMENT OF RGB CIRCUIT | 40 ~ 43 |

3. PARTS LIST

| | |
|---|---------|
| NOTE | 44, 45 |
| PACKING | 46 |
| PACKING PARTS LIST | 46 |
| EXPLODED VIEW | 47, 48 |
| SYSTEM ASSEMBLY REPLACEMENT PARTS LIST | 49 |
| PRINTED CIRCUIT BOARD PARTS LIST | |
| 1. CAW-1520A MAIN BOARD | 50 ~ 53 |
| 2. CAW-A012A IMAGER BOARD | 54 |
| 3. CAW-4511A RGB & POWER BOARD | 55, 56 |
| 4. CAW-8511A GEN-LOCK BOARD | 57 |

4. STANDARD CIRCUIT DIAGRAM

1. INTRODUCTION AND REPAIR SERVICE

WARNING:
TO PREVENT FIRE OR SHOCK HAZARD, DO NOT
EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION:
To prevent electric shocks and risk of fire hazards, do NOT use other
than the specified power source.

CAUTION:
To reduce the risk of electric shock, do not remove cover (or back). No
user-serviceable parts inside. Refer servicing to qualified service
personnel.

Thank you for purchasing this JVC colour video camera head.

The TK-870E is a colour video camera head using a single CCD (Charge
Coupled Device) solid-state pick-up element.

This camera head is for use in an image processing system (processing
system for picture composition, graphics, editing, synthesis, measurement,
recognition, analysis etc) shooting such material as images of paintings,
photographs, real subjects etc. for processing.

This instruction book is divided into three sections: English, German and
French.

• English Pages 2-17
• German Pages 18-33
• French Pages 34-49

2

CONTENTS

| | |
|--|----|
| FEATURES..... | 3 |
| PRECAUTIONS | 4 |
| CONTROLS, CONNECTORS AND INDICATORS..... | 5 |
| (Name of Parts and Functions) | |
| CONNECTIONS | 13 |
| ADJUSTMENTS FOR SYNCHRONIZED CONNECTIONS | 15 |
| AGC (Automatic Gain Control)..... | 16 |
| SPECIFICATIONS | 17 |

FEATURES

- Equipped with solid state CCD (Charge Coupled Device) image pickup element
Excellent print quality free of afterimages. No image distortion. Shock and vibration resistant.
- High resolution (horizontal resolution 320 lines)
Excellent colour reproduction with RGB primary colour filter system
- C-mount type lens mount
Compatible with the HZ-C811AF(U) video camera lens which features 6:1 power zoom capability, auto-focus and auto iris (optional) as well as any one of several C-mount lenses for use with 2/3" TV camera.
- Two types of video signal output
Composite video signals (2 sets) and RGB signals (1 set) can be output.
- Easy installation and operation
 - Screw fittings on both the top and bottom of the unit allow it to be mounted from above or below, depending on installation requirements.
 - Synchronous coupled circuits make this camera adaptable for a wide range of uses.
 - Convenient flange focal distance (distance between lens mount and image forming surface) fine adjustment controls on the outside of the unit.
 - Aluminium body.

3

PRECAUTIONS

To prevent malfunctions, electric shocks, damage, deformation or degradation, take the following precautions.



- In case of abnormal operation (smoke, strange sound or odour, etc.), stop using the camera and have it serviced by your nearest dealer.
- Do not aim the camera lens directly at the sun or any other extremely bright object.
- Never disassemble any part of the camera.
- Do not allow flammable objects, metal objects, water or sand to get inside the camera.
- Do not subject the camera to excessive shocks or vibrations.
- Do not expose the camera to rain or moisture.
- Do not use or store the camera:
 - in excessively hot, humid or cold places
 - around oily smoke or steam
 - near heating appliances
 - in dusty places
 - in the proximity of a strong magnetic field or where an electric signal is generated
 - in places with risk of fire
- Do not expose the camera to volatile liquids, and do not allow rubber or vinyl objects to come into contact with the unit for prolonged periods of time.

Cleaning

- Do not use benzine or thinner.
- Use a soft cloth to wipe dirt from the body and control panel.
- Only use camera air blower bulbs or lens cleaning paper (sold in camera shops) to clean the lens.


4

CONTROLS, CONNECTORS AND INDICATORS (Names of Parts and Functions)



5


- ① **Lens mount**
C-mount type lens mount (1" -32UN).
Use the HZ-C811AF(U) (F1.2, f=11-86mm, auto-focus, auto iris control, 8:1 power zoom lens) video camera lens or mount a C-mount lens designed for use with a 2/3-inch CCTV (Closed Circuit TV) camera.
- Note:**
"L" is the distance between the lens surface and mount surface (see the diagram below). Only lenses where "L" does not exceed 6.5mm (1/4") can be used.



- ② **Lock screw (LOCK)**
This screw is used to prevent error in the flange focal distance once it has been adjusted.
This screw should be loosened to make the flange focal distance adjustment (by rotating the focus screw), and re-tightened afterwards.
- ③ **Focus screw (FOCUS)**
This screw is to adjust flange focal distance necessary for correct focusing of each lens.
To adjust the flange focal distance, rotate this screw to optimize the focus.
Before adjusting, release the lock by loosening the lock screw. When finished making the adjustment, tighten the lock screw again.
- ④ **Dust cap**
When the lens is not mounted on the camera head, cover it with the dust cap to protect the internal parts from dust or damage.
* The dust cap (provided) has been attached to the lens mount when leaving the factory.
- ⑤ **Camera fixing holes**
Use these holes to fix the camera (1/4" -20UN).
This camera can be mounted either from the top or the bottom using the two fittings on the tripod plate pictured in the diagram on the next page. The tripod plate with mount fittings is attached to the bottom of the unit.

6

- **Movable mounting plate**
Some installation arrangements will require mounting from the top of the camera. To do this, top plate and tripod plate (with mount fittings) have to be switched. (See diagram below.) Both plates are attached to the camera by four screws. Removing these screws will free the plates. Since the size and fittings are identical the tripod plate will mount easily onto the top of the camera. Remount the top plate, then, to the bottom of the camera.



- ⑥ **TINT control knob (TINT)**
This is used for making fine adjustments to the tint.
Tint is subject to change due to the type of lens used and the colour temperature at the time of shooting.
When shooting a white subject, adjust so that the image on the video monitor is of the same whiteness.



B : Increases the amount of blue
R : Increases the amount of red

Note:
Be sure to use a correctly adjusted video monitor and recheck the white balance switch selector position.

7

- ⑦ **Power Indicator (POWER)**
The LED lights to indicate that the power is supplied to the camera head.
- ⑧ **Video signal output connector (VIDEO OUT)**
The video signal is output from this connector (BNC). Connect to the video monitor or recorder.
- ⑨ **Sync reference signal input connector (REF. IN)**
Use this connector to supply the composite video (VBS) or black burst (B.B.) signal used as the sync reference signal for the gen-lock operation (BNC connector).
When the gen-lock reference signal is input, the synchronization mode of the camera is switched automatically internal to external (gen-lock).
(When operating the camera by internal synchronization, remove this connector)
Note:
Gen-lock is not available if the external sync reference input is below -6 dB of the reference level.
Reference level: VBS = 140 IRE
B.B. = 40 IRE
- ⑩ **DC 12V power supply socket**
When the camera head is to be powered by DC 12V, supply the power via this DIN type 4-pin socket.
Use the AC adaptor AC-C322 or AC-C424 (optional). Connection of this to the camera head is by the power cord provided.
Use a DC 12V power source with a ripple voltage rating of less than 50mV. (Power supply current should exceed 700mA.)

Pin Assignment
• Power supply socket (DIN 4-pin)




| Pin No. | Signal |
|---------|--------|
| 1 | DC 12V |
| 2 | DC 12V |
| 3 | Ground |
| 4 | Ground |

• The connection between pins 1 and 2 and that between pins 3 and 4 are both jointed inside.
Make sure that the plug to be connected to this socket has the same configuration.

8

• **Power cord (provided)**
(DIN 4-pin - Round 10-pin)



| Pin No. | Signal |
|---------|--------|
| 1 | DC12V |
| 2 | DC12V |
| 3 | Ground |
| 4 | Ground |

| Pin No. | Signal |
|---------|--------|
| 1-8 | Ground |
| 9 | Ground |
| 10 | DC12V |

- ⑪ **Auto-Iris socket**
When using lenses other than the HZ-C811AF(U) video camera lens, the iris connector for the lens being used is plugged into this socket.
Note:
Use a lens with a current consumption of less than 50mA.


Pin Assignment
• Auto-Iris socket (3-pin)



| Pin No. | Signal |
|---------|------------------|
| 1 | Ground |
| 2 | Video |
| 3 | DC9V (Max. 50mA) |

9

• Iris plug (provided) (3-pin)



• When there are differences in iris plugs, use the accessory iris plug (3-pin).

⑫ White balance switch


- ☀: The preset white balance setting for indoor light (approx. 3,200K) is selected.
- ☀: The preset white balance setting for outdoor light (approx. 5,500K) is selected.

⑬ Auto-Focus lens socket (AF LENS)

This is for connection of the lens plug for the video camera lens HZ-C811AF(U) (F1.2, $\pm 11-66$ mm, auto-focus, auto iris control, 6:1 power zoom lens).

Pin Assignment

• Auto-Focus lens socket (DIN 6-pin)



| Pin No. | Signal |
|---------|-------------------------|
| 1 | DC12V |
| 2 | Ground |
| 3 | DC4V (Max. 50mA) |
| 4 | — |
| 5 | Iris control DC voltage |
| 6 | Ground |

10


⑭ R/G/B/REF./VIDEO signal output socket (R/G/B/REF./VIDEO OUT)

This is the output socket for RGB signals, composite sync reference signals and composite video signals (D-Sub 9-pin).

This socket connects necessary signal outputs for image processing to the image processing system input terminal.
Use a connecting cable suitable for connection between the video camera and image processing system sockets or a cable with an impedance of 75 ohms. (The cable should be as short as possible.)
When using a BNC plug for the image processing system input, use the VC-451-2E (cable length: approx. 2m (6.6 feet)) camera cable (optional). For D-sub 9-pin input terminals, use VC-452-2E (cable length: approx. 2m (6.6 feet)) D-sub—D-sub cable (optional).

Pin Assignment

• R/G/B/REF./VIDEO signal output socket (D-sub 9-pin)




| Pin No. | Signal |
|---------|--------------------------|
| 1 | Ground |
| 2 | Ground |
| 3 | R (RED) |
| 4 | G (GREEN) |
| 5 | B (BLUE) |
| 6 | Composite video |
| 7 | Composite sync reference |
| 8 | Ground |
| 9 | Ground |

• Use 2.6mm-diameter screws (millimetric pitch screw) when attaching plug.

11


• Camera cable VC-451-2E (optional).
(D-sub 9-pin — BNC x 5)



• Use 2.6mm-diameter screws (millimetric pitch screw) when attaching plug.

| Pin No. | Signal |
|---------|--------------------------|
| 1 | — |
| 2 | Ground |
| 3 | R (RED) |
| 4 | G (GREEN) |
| 5 | B (BLUE) |
| 6 | Composite video |
| 7 | Composite sync reference |
| 8 | Ground |
| 9 | Ground |

• D-sub—D-sub cable VC-452-2E (optional).
(D-sub 9-pin — D-sub 9-pin)



• Use 2.6mm-diameter screws (millimetric pitch screw) when attaching plug.


| Pin No. | Signal |
|---------|--------------------------|
| 1 | Ground |
| 2 | Ground |
| 3 | R (RED) |
| 4 | G (GREEN) |
| 5 | B (BLUE) |
| 6 | Composite video |
| 7 | Composite sync reference |
| 8 | Ground |
| 9 | Ground |

12

CONNECTIONS


- Do not turn power on until connections are completed.
- Refer to the instruction manuals of the connected equipment for further information.

(Connections Layout)



13


(Basic Connections Layout)



14

ADJUSTMENTS FOR SYNCHRONIZED CONNECTIONS

In case of synchronized connection, it may be necessary to coordinate the camera video adjustment settings depending on cameras to be used. After connection, adjust the horizontal phase (H PHASE) and colour subcarrier phase (SC PHASE). (It may not be necessary if there is no synchronized connection. There is no relation between this and R.G.B signals either.) Remove the top plate (with four screws) and adjust from the adjustment holes under it.



15

- 1) Horizontal phase adjustment (H PHASE)
Rotate the H phase adjustment variable resistor for optimum horizontal phase.
- 2) Colour subcarrier phase adjustment (SC PHASE)
Change the setting of the SC phase coarse adjustment switch (1, 2, 3) in conjunction with the SC phase fine adjustment variable resistor to obtain maximum monitor colour gain.

* For details, consult your dealer

Note:

Gen-lock operation is not possible using a signal containing several jitters such as video recorder playback signal.

AGC (Automatic Gain Control)

The AGC circuit incorporated in the camera head boosts the sensitivity automatically when the illumination on the subject is insufficient. The AGC on-off switch is provided inside the camera, and has been set to ON (AGC operational) when the camera left the factory. When the AGC function operates, the image becomes slightly more grainy. If the AGC function is not required, ask your dealer to turn the switch off.


SPECIFICATIONS

| | |
|----------------------------------|---|
| Type: | Colour video camera head |
| Colour system: | PAL standard |
| Pickup element: | 2/3" solid-state CCD (Charge Coupled Device) |
| Effective pixels: | 500H x 582 V |
| Scanning: | 625 lines, 2:1 interlaced |
| Synchronizing system: | Internal/external Automatic switching |
| Sync reference signal input: | Composite video signal (VBS)/1.0Vp-p, 75 ohms terminated (or black burst signal (B.B.)) |
| Sync reference signal output: | Connector: BNC Composite sync reference signal/ approx. 0.3Vp-p, 75 ohms, unbalanced Socket: D-sub 9-pin Composite video signal/1.0Vp-p, 75 ohms, unbalanced (2 outputs: BNC connector/D-sub 9-pin socket) R.G.B video signal/0.7Vp-p, 75 ohms, unbalanced (1 output: D-sub 9-pin socket) |
| Video signal output: | 45dB |
| Video S/N ratio: | 320 TV lines (horizontal) |
| Resolution: | 20Lux (F1.4 lens, AGC operational) |
| Minimum object illumination: | 2,000 lux |
| Recommended object illumination: | Indoor (approx. 3,200K)/Outdoor (approx. 5,500K, switchable) |
| White balance settings: | C-mount |
| Lens mount: | DC12V (±10%) |
| Power requirement: | Ripple voltage: less than 50mV |
| Power consumption: | 6.7 VA |
| Operating temperature range: | -5 to +40°C (23 to 104°F) |
| Operating humidity: | Less than 90% (without moisture condensation) |
| Dimensions (W x H x D): | 88 x 85 x 158mm, (3-1/2" x 3-3/8" x 6-1/4"), without dust cap |
| Weight: | About 880g (1.9 lbs.), without dust cap |
| Provided accessories: | Dust cap x 1 Power cord x 1 Ins plug (for ins socket) x 1 |

Design and specifications subject to change without notice.

17

SPECIFIC SERVICE INSTRUCTIONS & PRECAUTIONS



■ Specific Service Items and Precautions


1. Setting the white balance switch

The white balance switch can be set without removing the body cover; it should be set in accordance with light conditions prevailing at the set-up location of the camera head to compensate for varying colour temperatures. The table below shows the three switch settings and their corresponding colour temperatures; use it as a guide for properly setting the switch.

| Switch setting | | Colour temperature |
|----------------------------|--|--------------------|
| INDOORS | | Circa 3,200°K |
| OUTDOORS (medium sunlight) | | Circa 5,500°K |

2. R/G/B, REF/VIDEO OUT connectors

For the R/G/B, ref. and video signal outputs.




| Pin No. | 1 | 2 | 3 | 4 |
|---------------|------------|-------------------------|-------|-------|
| Terminal Name | GND (MAIN) | GND (COMP. VIDEO, SYNC) | R-OUT | G-OUT |

| 5 | 6 | 7 | 8 | 9 |
|-------|-----------------|----------------|-----|-----|
| B-OUT | COMP. VIDEO OUT | COMP. SYNC OUT | GND | GND |

AUTO IRIS terminals

The IRIS plug of the mounted lens is to be plugged into this terminal.

● **IRIS terminal pin assignment**




| Pin No. | Pin designation |
|---------|-----------------------|
| ① | GND |
| ② | Video |
| ③ | +9V DC (50mA max.) |

4. VIDEO OUT terminal

For video signal output. Connect the VIDEO IN terminal of a video monitor or VCR to the terminal.

5. REF IN terminal

For inputting the composite video signal (1 Vp-p) which forms the external sync reference or black burst signal.

6. DC 12 V input terminal

| Pin No. | Pin designation |
|---------|-----------------|
| ① | +12 V |
| ② | " |
| ③ | GND |
| ④ | " |

7. AF (AUTO FOCUS) LENS connector

Connect the plug of the optional exclusive lens.



| Pin No. | 1 | 2 | 3 | 4 | 5 | 6 |
|---------------|-----------|--------------|----------|---|-------|----------------|
| Terminal Name | 12V DC | GND (12V) | 9V DC | — | VIDEO | GND (VIDEO) |

8. Adjustment

- (1) In this camera head, the back focus can be adjusted from the outside. After adjusting, turn the LOCK adjusting screw clockwise to lock it.
- (2) Tint volume
Factory setting: Mechanical center (click position)
Some lens will be produce no good white balance. Adjust the tint VR when white balance is not good with used lens.
- (3) When the top plate is removed, the H PHASE VR, SC PHASE VR and phase select switch adjustments can be performed.

● **H PHASE (horizontal phase) control**

For adjusting the horizontal phase of the camera video signal outputs, by comparing the phases between the camera video signal and the external sync reference signal.

● **SC PHASE (colour phase) control**

For adjusting the SC phase of the camera video signal outputs to match the colour phases of the cameras connected to one another, by comparing the phases between the camera video signals and the external sync reference signal.

● **PHASE SELECT switch**

If the phase cannot be adjusted by the H PHASE and SC PHASE VRs, change the setting of this switch. It is set at 3 position at the factory, and can be set to 1 or 2 position.

9. Factory switch settings

The switches have been set as shown below at the factory before shipping.

- White balance switch: INDOOR
- AGC switch : ON (In the PC board)
- TINT VR : Click position

■ Two-sided hole-through PC Board

A two-sided hole-through PC Board is used on this camera. Patterns and wires are designed extra thin to attain highdensity component mounting. Rough handling may damage the patterns/wires or other components. When disassembling, repairing or adjusting the PC boards, exercise care to avoid damage.

■ Repairing circuit board modules

(1) Removing circuit board module

Pull out the circuit board, after removing solder completely with a solder sucker.

NOTE:

- Take care not to damage or remove solder from other parts.
- If more than two circuit boards are removed, make sure that they are replaced in the proper positions.

■ Replacing chip components

Use a soldering iron (temperature 260° ~ 300°C, about 17W) with a slim tip and high insulating ability. Those with a solder sucker (about 55W) are usually easier to use.

NOTE: This video camera uses many mini-flat ICs. To remove these, melt the solder while picking up the individual pin with fine tipped tweezers or cut off the IC pins. Take care not to scratch or peel off the BOARD foil pattern.

■ Chip components display

Besides the resistors, short jumpers, FET's, ceramic capacitors, transistors, and other chip components, the chip tantalum capacitors and chip variable resistor (CH VR) are used on the camera. None of these chip components are reusable again once they have been used.

NOTE: 1. Avoid rough handling of the VR

2. Use a thin-tip insulated-type screwdriver to adjust the CH VR.

● How to read printings

On certain chip components, printing is applied as follows:

① Chip metal glaze resistor (CH MG R)

The diagram shown in Fig. A ① is applied to some of these resistors.

Reading method (Example)

$$\begin{array}{c} 1 \quad 2 \quad 3 \\ \hline 12 \quad 3 \end{array} = 12 \times 10^3 \quad \text{Unit: } [\Omega]$$

② Shorting jumper (0 $[\Omega]$ of CH MG R)

No diagram is applied to shorting jumpers. A "0" is printed on Type ① shown in Fig. A.




Fig. A Example of CH MG R/CH C Cap. codes

③ Chip ceramic capacitor (CH C Cap.)

- the diagram shown in Fig. A ② is applied to some of the CH C Caps. On some others, there is no diagram that is of any use to users.

Reading method (Example)

$$\begin{array}{c} 1 \quad 2 \quad 3 \quad K \\ \hline 12 \quad 3 \end{array} = 12 \times 10^3 \quad \text{Unit: [PF], Tolerance: K (}\pm 10\%)$$

- As shown in Fig. B some chip ceramic capacitors are represented by two digits. Table A shows how those figures should be read.




Fig. B Example of CH C Cap.

| Alphabet | A | B | C | D | E | F | G | H | J | K |
|------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----|-----|------------------|------------------|
| Constant | 1.0 | 1.1 | 1.2 | 1.3 | 1.5 | 1.6 | 1.8 | 2.0 | 2.2 | 2.4 |
| Alphabet | L | M | N | P | Q | R | S | T | U | V |
| Constant | 2.7 | 3.0 | 3.3 | 3.6 | 3.9 | 4.3 | 4.7 | 5.1 | 5.6 | 6.2 |
| Alphabet | W | X | Y | Z | | a | b | d | e | f |
| Constant | 6.8 | 7.5 | 8.2 | 9.1 | | 2.5 | 3.5 | 4.0 | 4.5 | 5.0 |
| Alphabet | m | n | t | y | | | | | | |
| Constant | 6.0 | 7.0 | 8.0 | 9.0 | | | | | | |
| Numeral | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| Multiplier | 10 ⁰ | 10 ¹ | 10 ² | 10 ³ | 10 ⁴ | 10 ⁵ | | | 10 ⁻² | 10 ⁻¹ |

Table A CH C Cap. capacity value

④ Chip Variable Resistor (CH VR)

A two-digit code is printed on some CH VRs. They indicate a reading method, as shown in Table B.

Three-digit codes are also used, these codes are read in the same way as those for CH MG R.

⑤ Chip Tantalum Capacitor (CH Tan. Cap.)

The diagram shown in Fig. C is applied to some of the CH Tan. Caps.

Reading method (Example)

The type shown in Fig. C is 10 μ F, 16V chip tantalum capacitor.




Fig. C Example of CH Tan. C Cap. codes

⑥ Chip Transistor

The labels shown in Table C are applied to the chip transistor.

| Part No. | Display method |
|----------------|--|
| 2SC2778(B,C,D) | K . B K . C K . D denotes 2SC2778 parts ranking : B |
| 2SC2404(D) | U . D |
| 2SD601(Q,R) | Y . Q Y . R |
| 2SD601A(Q,R) | Z . Q Z . R |
| 2SD1030(R) | iZR |
| 2SB709(P-R) | A . P A . Q A . R |
| 2SB792(Q-T) | I . Q I . R I . S I . T |
| 2SB970(Q-S) | 1RQ 1RR 1RS |
| 2SA1022(C) | E . C |

Table C Chip transistor labels

⑦ Chip FET

The following printing is applied to the Chip FET.

| Part No. | Display method |
|-------------|--|
| 2SK198(Q,R) | 10 . Q 10R denotes 2SK198 parts ranking : Q |
| 2SK316 | 1KP 1KQ |

Table D Chip FET codes

⑧ Chip Diode

The following labels are applied to the Chip Diode.

| Part No. | Display method |
|-------------|------------------------|
| MA151WA | M . N denotes MA151 |
| MA151K | M . H |
| MA151WK | M . T |
| MA151A | M . A |
| MA157 | M . R |
| MA3051 | 5.1 |
| MA3120(L-H) | 12H 12L 12M |

Table E The display of chip diode

| Code | 12 | 22 | 32 | 52 | 72 | 13 | 23 | 33 | 53 | 73 | 14 |
|------------------|---------------|---------------|---------------|---------------|----------------|----------------|----------------|----------------|----------------|----------------|---------------|
| Resistance Value | 100 Ω | 220 Ω | 330 Ω | 470 Ω | 680 Ω | 1 k Ω | 2.2 k Ω | 3.3 k Ω | 4.7 k Ω | 6.8 k Ω | 10 k Ω |
| Code | 24 | 34 | 54 | 74 | 15 | 25 | 35 | 55 | 75 | 16 | |
| Resistance Value | 22 k Ω | 33 k Ω | 47 k Ω | 68 k Ω | 100 k Ω | 220 k Ω | 330 k Ω | 470 k Ω | 680 k Ω | 1 M Ω | |

Table B CH VR resistance value display method in two-digit

"CHARGE COUPLED DEVICE (CCD)" IMAGER

1. **Precautions for handling and replacing CCD imager**
 CCD is characteristic of many advantages, but it also has some disadvantages. The following are measures to deal with these disadvantages.

- (1) CCD imager is a circuit element which is very sensitive to static electricity.
 - The potential differences caused by the electrostatic charge – which have been accumulated in the clothing and human body – sometimes destruct the insulation of the CCD imager. Therefore, handle the "high-priced" CCD imager with more attention thereto than to the C-MOS (Complementary MOS), especially during the dry season and in dry places.
 - Maintain the CCD imager in the provided pack or aluminum foil so that it can be kept at the same potential. Never unpack its container until the very moment of servicing.
- (2) The CCD imager is easily damaged by dust. Also it suffers considerable deterioration, when exposed to strong light.
 - When servicing, make sure that the CCD imager is kept free from such foreign material as dust. Use dry soft cloth or soft cloth moistured with ethylalcohol to wipe off the foreign material.
 - Do not exposed the CCD imager to such strong light as direct sunlight.
- (3) The CCD imager is damaged instantly by the following malfunctions. Pay close attention to these malfunctions before servicing.
 - ① The voltage of only the 20-V Line has dropped.
 - ② The output terminal of the pin (11) is short-circuited.
 - ③ The PD (pre-charged drain bias) terminal of the pin (14) has turned negative.

2. **Arranging CCD imager and ROM (for compensating the CCD imager) in pairs**

- Both the "CCD imager mounted on the imager board" and the "ROM mounted on the main board" are arranged in pairs to optimize their individual characteristics. Neither the CCD imager nor ROM can be replaced individually, because each ROM is manufactured to conform to the requirements for its corresponding CCD imager. (Each ROM has its own "pair number" sealed.)

NOTE:

- No ROMs are provided with some CCD imagers which do not require compensation.
- The adjusting ROM is installed in the shielded case on the bottom of the main board.

3. **Supply and replacement of individual CCD imagers and compensating ROMs (Refer to Table 1.)**

- The CCD imagers supplied for servicing are available in two types according to the characteristics. Service as follows depending upon the given situation:

- (1) **When a pair of CCD imager and the compensating ROM is supplied at the same time (with its pair numbers sealed individually)**

- Replace the CCD imager and the compensating ROM at the same time.

When the compensating ROM is not mounted on the main PC board, install the newly-supplied compensating ROM after removing the four chip jumpers.

- (2) **When only a CCD imager is supplied (without its corresponding ROM)**


- Replace the CCD imager only, since no compensation is required for the CCD imager.

However, if the compensating ROM is also defective, also remove the ROM and then install the four chip jumpers for shorting at the specified positions.

4. **Supply and replacement of imager board ass'y and main board ass'y (Refer to Table 2)**

The PC board ass'y supplied for service parts has no CCD imager or compensating ROM. Use the CCD imager and the ROM by removing them from the repair set.

- When the compensating ROM is not installed on the board for repair, replace the whole of the board.
- When the compensating ROM is installed on the board for repair, the ROM should also be replaced. In this case, first remove the four chip jumpers from the newly-supplied board, then remove the compensating ROM from the board for repair and install it on the supplied board.



**Table 1 Replacement of CCD and ROM for PAL
(When CCD/ROM is defective)**
















| Item | Case 1 | Case 2 |
|-------------------------|--|---|
| Condition of repair set | <ul style="list-style-type: none"> ● CCD (without ROM) ● With chip jumpers | <ul style="list-style-type: none"> ● CCD (with ROM) |
| Supplied parts |  <p>Chip jumper (x 4) (J401 - J404) (* Note 1)</p> <p>Main board</p> <p>(Rear view)</p> |  <p>Main board</p> |
| CCD only |  <p>① Replace the ROM. (Leave the chip jumpers as they are.)</p> <p>Main board</p> |  <p>① Replace the CCD. (Leave the ROM as it is.)</p> <p>② Remove the defective ROM. ③ Install the specified chip jumpers at four points. (* Note 1)</p> <p>③ Chip jumper (x 4) (J401 - J404) (* Note 1)</p> <p>Main board</p> |
| CCD + ROM |  <p>① Replace the CCD. ② Remove the chip jumpers. (* Note 1) ③ Install the ROM.</p> <p>② Chip jumper (x 4) (J401 - J404) (* Note 1)</p> <p>Main board</p> |  <p>① Replace the CCD. ② Replace the ROM.</p> <p>Main board</p> |

Table 2 When PC Board is defective (For PAL)
(Also replace CCD/ROM when CCD/ROM is defective)

| Item | Case 1 | Case 2 |
|---|--|---|
| <p>Condition of repair set</p> <p>Supplied board (without ROM, with chip jumpers)</p> | <p>● CCD (without ROM)</p> <p>● With chip jumpers</p>   <p>(Rear view)</p> <p>Main board</p> | <p>● CCD (with ROM)</p>   <p>Main board</p> |
|  <p>● With chip jumpers (J401 - J404)</p> <p>● Without ROM</p> | <p>① Replace the board.</p>   <p>Main board</p> | <p>① Remove the chip jumpers from the supplied board. (* Note 1)</p> <p>② Remove the ROM from the repair board and install it on the supplied board.</p> <p>Note: When the ROM is also defective, replace the CCD/ROM too.</p> <p>① Chip jumper (x 4) (J401 - J404) (* Note 1)</p>  <p>② ROM</p> |

(* Note 1): The installing positions of the shorting chip jumpers are around the front side of the rear of the center main board.




■ SPECIAL CHARACTERISTICS OF A CCD

Smear phenomenon

This phenomenon occurs when shooting a very bright object (such as electronic light, fluorescent lamp, the sun or a strong reflection).


Video monitor screen



Due to the interline-transfer organization of the CCD image sensors (Refer to "The Interline-transfer Organization of the CCD Image Sensors"), this phenomenon is caused by electronic charges generated beneath the photosensors by a light with a long wavelength, such as an infrared light.

Patterned noise on the picture at high temperatures

Dark current (thermal noise) is inherent in semiconductors. At room temperature, the amount of dark current in all photosensors is very close but as the temperature rises, the amount of dark current increases. As a result, the relative difference between the dark current of each photosensor increases, and this difference causes the patterned noise on the picture.



False signal

When vertical stripes or straight lines are shot, they may look wavy.


Blemishes

The photosensor elements generate electronic charges which ultimately produce horizontal and vertical rows in the CCD image sensor.

Therefore, any malfunctioning photosensor element will eventually cause a blemish on the monitor screen.

The interline-transfer organization of the CCD image sensors

This CCD video camera module adopts an interline-transfer organization in which precisely aligned photosensors and vertical shift registers are arrayed interlinearly and a horizontal shift register links up with the vertical shift register, as shown. Light variations are sensed by the photosensors, which generate electronic charges proportional to the light intensity. The generated charges are fed into the vertical shift registers all at one. The charges are then transferred from the vertical shift registers to the horizontal shift registers successively and finally reach the output amplifier to be read out successively.



REMOVING CASINGS, COVERS AND OTHER COMPONENTS

■ Disassembling/Replacing Each Component

- Before removing components, be sure to cut off the power supply.
- When disassembling/replacing, be sure to mount the dust cap to protect the CCD imager and optical low-pass filter.

1-1. How to remove the body cover

- (1) Remove the four screws ③ shown in Fig. 1 to remove the top cover.
- (2) Remove the two screws ⑤ shown in Fig. 1 to remove the top cover ass'y by lifting it up.

1-2. How to remove the bottom cover

- (1) Remove the four screws ② shown in Fig. 1 to remove the tri-base ass'y.
- (2) Remove the two screws ④ shown in Fig. 1 to remove the bottom cover.

1-3. How to remove the main PC board

- (1) Remove the four screws ⑥ shown in Fig. 1, and both left and right mother PC boards can be removed.

1-4. How to remove the front cover

- (1) Remove the four screws ⑦ shown in Fig. 1.
* In this condition, each adjustment can be performed.

1-5. How to remove the rear plate and rear cover.

- (1) Remove the four screws ⑧ shown in Fig. 1.




Fig. 1

2-1. How to remove the top beam

Remove the four screws ④ shown in Fig. 2.

2-2. How to remove the terminal ass'y

Remove the four screws ⑤ shown in Fig. 2.

NOTE: Be careful not to cut the lead wires since they are left connected.

2-3. How to remove the CCD imager and imager PC board

- (1) Remove the two screws ③ shown in Fig. 2.
- (2) Disconnect four connectors and the grounding lead from the imager PC board. Now the CCD imager and imager PC board can be removed completely.




Fig. 2

3. How to disassemble the CCD imager

* Remove 2 nuts shown in Fig. 3 (A).

(1) Remove the imager PC board shown in Fig. 3 by pulling it in the direction of (B).

(2) Remove the two screws (a) shown in Fig. 3 to remove the CCD imager holder and the CCD imager.

NOTE: At this time, the imager rubber is removed, so take extra precaution not lose it.

(3) Remove the two screws (b) shown in Fig. 3, to remove the CCD imager.

(4) Remove two screws (c) shown in Fig. 3 so as to disassemble the CCD imager unit into the adjust B ass'y, C mount and adjust ring.

NOTE: At this time, the four springs are removed, however, do not lose them.

4. How to remove the optical low-pass filter

Remove the two screws (d) shown in Fig. 3, and the optical low-pass filter can be removed.

NOTE: The optical low-pass filter can also be removed by removing the dust cap from the outside.




Fig. 3







2. ADJUSTMENT

MEASURING INSTRUMENTS, TOOLS AND FIXTURES FOR ADJUSTMENT


■ MEASURING INSTRUMENTS

| | | | |
|--|--------|--|---|
| 1. Oscilloscope..... | 1 | 6. Power supply..... | 1 |
| 2. Color monitor TV (PAL-type, it is desirable that it is equipped with an RGB connector)..... | 1 | Voltage: 12 V DC | |
| Color temperature: 9,300K | | VTR power, AC adaptor or AC adaptor + Camera cable | |
| 3. Lights..... | 1 or 2 | 7. Vectorscope (PAL-type)..... | 1 |
| Color temperature: 3,200K | | Used only if necessary. | |
| 4. Frequency counter..... | 1 | 8. Waveform monitor (PAL-type)..... | 1 |
| 5. DIGITAL DC voltmeter (DVM)..... | 1 | Used only if necessary. | |

■ TOOLS AND FIXTURES

| 1. Patterns | | (Gray scale pattern) | (White pattern) | (Color bar pattern) |
|---|--|---|---|---|
| <p>Note: Reflection-type patterns eventually suffer from drops in signal output level or loss of output uniformity. Periodic replacement is recommended.</p> | |  |  |  |
| | | <p>GS-2A* Reflective type ($\gamma = 2.2$)</p> | <p>WC-2A* Reflective type</p> | <p>Reflective type CC-2A* Transmissive type: CC-2T*</p> |
| 2. DRIVERS | | 3. COLOR TEMP. CONVERSION FILTER | | 4. PIN CLIP |
|  <p>Adj. driver</p> | |  <p>KODAK wratten No. 80C, CC10C and No. CC10B gelatin filter</p> <p>80C + CC10C + CC10B</p> <p>When servicing, this unit can be adjusted using only the KODAK Wratten No. 80C gelatin filter or HOYA No. 80C filter</p> | |  <p>MJ-025*</p> <p>Slightly bending the pin tip facilitates its use.</p> |
| 5. LENS | | | | |
| <p>C-mount lens for 2/3" ITV camera Iris can be controlled manually.</p> <ul style="list-style-type: none">● Lens flange-back should be standard● Zoom lens is recommended | | <p>Note: Parts marked with an asterisk (*) can be ordered from the following section: PARTS SECTION OF THE SALES ENGINEERING DEPARTMENT, TELEVISION RECEIVER DIVISION. Parts that is not marked with asterisk (*) are able to get at your side.</p> | | |

INSTRUMENT CONNECTION AND SET UP




■ VIDEO CAMERA HEAD INSTALLATION ON TRIPOD

This camera provides an exclusive tripod mounting hole behind the bottom cover and the tri-base ass'y. Therefore, when adjusting the camera with the tripod mounted, it can be mounted temporarily to the tripod using either of the screwdriver insertion holes on the front bracket.

Notes:

- When mounting, be careful not to drive the screw of the tripod excessively. (If not, the camera might not be fixed.)
- Be sure to perform adjustment after confirming that the camera has been secured firmly.



PRIOR TO STARTING ADJUSTMENT

(1) Warming up

Before adjustment, turn on the camera to warm it up for more than 10 minutes so that the camera operation may be stabilized.

(2) Lighting

- Adjust the distance between the light and pattern so that the illumination on the pattern is about 2,500 lux and the illumination over the entire pattern surface is as uniform as possible.

- Correct adjustment will be impossible if the illumination is too high, too low or uneven.

(3) About CCD Imager

The CCD image is susceptible to static electricity. The insulator of this element might be damaged if a potential difference is caused by the electrostatic charge carried by clothes or body. Be careful when holding it because it is costly. Use special care in a dry atmosphere in a dry season.

ADJUSTMENT PROCEDURES

1. Presetting


Before adjustment, preset the following switches:

- 1) TINT VR "Click" position (center)
- 2) AGC switch "OFF" (opposite to lens)
- 3) White Balance switch "☀" (in-door)

2. In holding a test pin with a probe, take care set contact with any other pin. The CCD imager will be damaged if some test pins are accidentally connected.

3. Test points

- When the hinged connector is the point to be tested (such as when (24): 8.5V, (4): R-Y, (48): MAX)
- ① How to hold the pin of the hinged connector from the back of the board using probes.
- ② How to hold the pin of the hinged connector on the board surface directly with probes.



- Connect the ground cable to the ground terminal on the PC BOARD (e.g. (32) (GND) on the hinged connector).
If the ground cable is connected to the chassis frame, the waveform will be distorted.

4. EXT. TRIGGER

Connection to external trigger signal of oscilloscope
In adjusting the signal system, connect a 1 k Ω resistor to TP-309 (TP-ID) on Main PC BOARD to get the trigger signal if necessary.


5. JUST SCAN

Unless otherwise specified, apply "just scan" to all pattern adjustments.

6. Repeat adjustments optimum conditions are established.



7. Chip VR

Chip VR rotating position is designated as shown in the figure below for the convenience of explanation, since the chip VR can be rotated 360°.




8. No Adjustment of unspecified VRs

Never rotate VR's other than those specified by this Instruction Manual.

MAIN PARTS ARRANGEMENT AND LOCATIONS OF BOARDS


ADJUSTING STEP

1. ADJUSTMENT OF THE POWER





2. ADJUSTMENT OF THE SSG

NOTE: This adjustment is normally not necessary. It is possible to skip to the "ADJUSTMENT OF THE SIGNAL SYSTEM" of the next step.




3. ADJUSTMENT OF THE SIGNAL SYSTEM




4. ADJUSTMENT OF RGB CIRCUIT

[Proceed to this adjustment only after having completed the adjustments 1 to 3.]




ADJUSTMENT LOCATIONS

(REAR VIEW)




(RGB, POWER PC BOARD)




RGB BOARD


LENS



● PRESETTING


| | | |
|-------------------------------------|---|---|
| <p>A To obtain a picture</p> |  | <p>If a picture is not obtained, preset the following VRs as indicated. If a picture is already obtained or fine adjustment is to be made later, presetting is not necessary.</p> <p>R707 (PED SET) → Mechanical center R685 (Y KNEE) → Turn fully counter clockwise R25 (Y SET UP) → Mechanical center R26 (W CLIP) → Turn fully counter clockwise R29 (Y GAIN) → Mechanical center</p> <p>(Note) Set all VRs so that a picture and colour are obtained.</p> |
|-------------------------------------|---|---|

1. ADJUSTMENT OF THE POWER

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|-----------------|--------------------------------|--|-----------------|---|
| 1. | 8.5V Adjustment | DC Voltmeter | <p>②4 (8.5V)</p>  <p>(REAR VIEW)</p> | R503 (8.5V ADJ) | <p>Adjust R503 (8.5V ADJ) until the DC voltmeter indicate $8.5 \pm 0.05V$ on the scale.</p> <p>NOTE: Use a correctly calibrated DC voltmeter. See that a correct tester is always used.</p> |


2. ADJUSTMENT OF THE SSG





| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|----------------------|---|-----------------|-----------------|---|
| 1. | SSG Adjustment | <p>This adjustment is only done when repairing the SSG IC and peripherals that require adjustment.</p> <p>● In most cases, this adjustment is unnecessary. Proceed to "3. ADJUSTMENT OF THE SIGNAL SYSTEM."</p> | | | |
| A | 14MHz OSC Adjustment | Frequency counter DC power supply (DC 4.43V) | TP-fsc TP-DC | C25 (14M OSC) | <ol style="list-style-type: none"> 1. Apply 4.43V DC to TP-DC. 2. Rotate trimmer C25 (14M OSC) the frequency counter connected to TP-fsc indicates $17.734476 \text{ MHz} \pm 5 \text{ Hz}$. 3. Stop applying 4.43V to TP-DC. |
| B | 28MHz OSC Adjustment | Frequency counter | TP-fsc | C404 (28M OSC) | <ol style="list-style-type: none"> 1. Rotate trimmer C404 (28M OSC) the frequency counter connected to TP-fsc indicates $17.734476 \text{ MHz} \pm 5 \text{ Hz}$. |








3. ADJUSTMENT OF THE SIGNAL SYSTEM

| | | | | | |
|----|---------------------------------|--------------|------------------------------|----------------------------|---|
| 1. | MAX GAIN Adjustment | DC voltmeter | (48) (TP-MAX) | R678 (AGC MAX G.) | Adjust R678 (AGC MAX G) the DC voltmeter indicates $2.65\text{V} \pm 0.01\text{V}$ on the scale. |
| 2. | WHITE BALANCE Coarse Adjustment | DC voltmeter | (49) (R CTL) (50) (B CTL) | R658 (IN-B) R655 (IN-R) | <ol style="list-style-type: none"> 1. Set the WHITE BALANCE switch to "☀" (IN-DOOR) and, while measuring the voltage at (50) with a DC voltmeter, adjust R658 (IN-B) so that the voltage reading is $2.85 \pm 0.01 \text{ V}$. 2. While measuring the voltage at (49) with the DC voltmeter, adjust R655 (IN-R) so that the voltage reading is $2.75 \pm 0.01 \text{ V}$. |



| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|----------------------|--|--|---|---|
| 3. | IRIS SET Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | (b6) (CCD OUT) or ② PIN of [K] connector  Imager board | Iris control knob (LENS side) | <p>1. While observing the waveform at (b6) (CCD OUT), or ② Pin of [K] connector adjust the iris control knob so that the waveform is set at $150 \pm 1 \text{ mV}$ as shown in Fig. 3-1.</p>  <p>Fig. 3-1</p> <p>NOTE: Never bring CCD OUT Pin into contact with any other pin because the CCD imager should be damaged.</p> |
| 4. | R.G.B DET Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | TP-605 (TP-G DET) TP-604 (TP-R/B DET) | R687 (G.GAIN) R680 (R GAIN) R679 (B GAIN) | <p>● Observe the waveform at (b6) (CCD OUT) or ② Pin of [K] connector and make sure that the waveform is $150 \pm 1 \text{ mV}$ as shown in Fig. 3-1.</p> <p>● EXT-TRIGGER Apply external trigger with a signal passing through a resistance of $1 \text{ k}\Omega$ to TP-309 (TP-ID).</p> <p>1. Measure the waveform at TP-605, and adjust R687 (G.GAIN) so that the waveform is $300 \pm 1 \text{ mV}$ as shown in Fig. 4-1.</p>  <p>Fig. 4-1</p> <p>2. Measure the waveform at TP-604, and adjust R680 (R GAIN) and R679 (B GAIN) so that each waveform is $300 \pm 1 \text{ mV}$.</p>  <p>Fig. 4-2</p> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|---------------------|--|--|--|---|
| 5. | γ Adjustment | Oscilloscope (H-rate) (10:1) Gray scale pattern | TP-308 (T-G γ) | R684 (γ SET) | <ul style="list-style-type: none"> If the waveform is slightly collapsed or deformed, raise R707 (PED SET) sufficiently and release R685 (Y KNEE) by turning it fully counterclockwise before adjustment. This will facilitate adjustment. 1. Observe the waveform at TP-308 and adjust R684 (γ SET) so that the waveform is $400 \pm 3\text{mV}$-w.   <p>Fig. 5-1</p> |
| 6. | PEDESTAL Adjustment | Oscilloscope (H-rate) (10:1) | TP-308 (TP-G γ) TP-307 (TP-R/B γ) | R707 (PED SET) R683 (B OFF SET) R682 (R OFF SET) | <ul style="list-style-type: none"> EXT TRIGGER Apply external signal with a signal passing through a resistance of 1 kΩ to TP-309 (TP-ID). Using the lens cap, close the iris. 1. Observe the waveform at TP-308, and adjust R707 (PED SET) so that the waveform is $40 \pm 2\text{mV}$ (center to center) as shown in Fig. 6-1. 2. Observe the waveform at TP-307, and adjust R683 (B OFFSET) and R682 (R OFFSET) so that each waveform is $40 \pm 2\text{mV}$ (center to center) as shown in Fig. 6-2.   <p>Fig. 6-1</p>  <p>Fig. 6-2</p> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|------------------------------------|---|--|--|---|
| 7. | OUTPUT WAVE-FORM LEVELs Adjustment | Dual-trace oscilloscope Gray Scale pattern | TP-301 (TP-G ₀) TP-302 (TP-G ₁) TP-303 (TP-G ₂) TP-306 (TP-R ₀ /B ₀) TP-305 (TP-R ₁ /B ₁) TP-304 (TP-R ₂ /B ₂) | R125 (G ₁ GAIN) R123 (G ₂ GAIN) R124 (R ₁ /B ₁ GAIN) R122 (R ₂ /B ₂ GAIN) | <ul style="list-style-type: none"> ● Observe the waveform at (b6) (CCD OUT) or pin ② of the connector [K]. Adjust the iris control knob so that the waveform is set at 150 mV as shown in Fig. 3-1. <ol style="list-style-type: none"> 1. Connect TP-301 to the channel-1 side. 2. Connect TP-302 to the channel-2 side. Then invert one channel of the oscilloscope and set the oscilloscope to the ADD mode. Adjust R125 (G₁ GAIN) so that the waveform becomes linear as shown in Fig. 7-1. 3. Connect TP-303 to the channel-2 side. Then invert one channel of the oscilloscope and set the oscilloscope to the ADD mode. Adjust R123 (G₂ GAIN) so that the waveform becomes linear as shown in Fig. 7-1. 4. Connect TP-306 to the channel-1 side. 5. Connect TP-305 to the channel-2 side. Then invert one channel of the oscilloscope and set the oscilloscope to the ADD mode. Adjust R124 (R₁/B₁ GAIN) so that the waveform becomes linear as shown in Fig. 7-1. 6. Connect TP-304 to the channel-2 side. Then invert one channel of the oscilloscope and set the oscilloscope to the ADD mode. Adjust R122 (R₂/B₂ GAIN) so that the waveform becomes linear as shown in Fig. 7-1. |






















Fig. 7-1





NOTE: If a dual-trace oscilloscope is not available, adjustment should be done so that each wave form level is equal.




| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|----------------------------|------------------------------------|------------|-------------------------------------|---|
| 8. | MPX Adjustment | Oscilloscope (H-rate) (10:1) | ④ (R-Y) | R127 (MPX-DC) | <ul style="list-style-type: none"> ● EXT. TRIGGER Apply external trigger to TP-309 (TP-ID), using a signal passing through a 1 kΩ resistor. 1. Measure ④ (R-Y), and adjust R127 (MPX-DC) to make the waveform linear.   <p>Fig. 8-1</p> |
| 9. | CARRIER BALANCE Adjustment | Oscilloscope (H-rate) (10:1) | VIDEO OUT | R19 (CAR BAL 90) R20 (CAR BAL 0) | <p>Procedures of adjustment with oscilloscope</p> <ul style="list-style-type: none"> ● Close the iris by applying the lens cap. 1. Measure VIDEO OUT, and adjust R19 (CAR BAL 90) and R20 (CAR BAL 0) by turns so as to minimize the carrier as seen in Fig. 9-1.  <p>Fig. 9-1</p> |
| | | Vectorscope | VIDEO OUT | R19 (CAR BAL 90) R20 (CAR BAL 0) | <p>Procedures of adjustment with vectorscope</p> <ul style="list-style-type: none"> ● Close the iris by applying lens cap. ● Carrier can be easily adjusted at near the zero point by increasing the gain of the vectorscope. 1. Adjust R19 (CAR BAL 90) and R20 (CAR BAL 0) by turns to set the carrier at the center of the vectorscope.  <p>Fig. 9-2</p> |



| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|--------------------------|--|--|--|--|
| 10. | Y.SET UP Adjustment | Oscilloscope (H-rate) (10:1) Gray scale pattern Y.GAIN R29 R25 Y.SET UP | VIDEO OUT  | R25 (Y.SET UP) R29 (Y GAIN) | <ul style="list-style-type: none"> ● If the top of the waveform may be clipped turn R685 (Y KNEE) and R26 (W CLIP) until the waveform will not surpress. <ol style="list-style-type: none"> 1. Close the iris by applying the lens cap. 2. Measure VIDEO OUT, and adjust R25 (Y. SET UP) so that the waveform becomes $50 \pm 2\text{mV}$ as shown in Fig. 10-1.  <p style="text-align: center;">Fig. 10-1</p> <ol style="list-style-type: none"> 3. Remove the lens cap. 4. Observe the waveform at b6 (CCD OUT), or ② Pin of K connector and make sure that the waveform is $150 \pm 5\text{mV}$ as shown in Fig. 3-1. 5. Measure VIDEO OUT, and adjust R29 (Y GAIN) so that the waveform become 700 mV as shown in Fig. 10-2.  <p style="text-align: center;">Fig. 10-2</p> <ol style="list-style-type: none"> 6. Repeat steps 1 and 2 so that the level of the waveform at VIDEO OUT becomes that shown in Fig. 10-3.  <p style="text-align: center;">Fig. 10-3</p> |
| 11. | AUTO IRIS SET Adjustment | Oscilloscope (H-rate) (10:1) Gray Scale pattern | VIDEO OUT  | R614 (AUTO IRIS) | <ul style="list-style-type: none"> ● Connect the auto iris connector of the lens side to the auto iris connector of the camera. <ol style="list-style-type: none"> 1. Adjust R614 (AUTO IRIS) so that the waveform present at the video out jack be comes 700 mV as shown in Fig. 11-1. <p>NOTE: This adjustment can be applied only to the lens having an auto iris function.</p>  <p style="text-align: center;">Fig. 11-1</p> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|-----------------------|---|---------------|-----------------|---|
| 12. | Y KNEE Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | TP-308 (TP-G) | R685 (Y KNEE) | <ul style="list-style-type: none"> ● Turn R26 (W CLIP) fully counterclockwise to release them. 1. Open the iris sufficiently. 2. Measure TP-308, and adjust R685 (Y KNEE) so that the peak level of the waveform is set at $600 \text{ mV} \pm 5 \text{ mV}$. |
| | |  | | |  <p>Fig. 12-1</p> |
| 13. | WHITE CLIP Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | VIDEO OUT | R26 (W CLIP) | <ul style="list-style-type: none"> 1. Open the iris sufficiently. 2. Adjust R26 (W CLIP) so that the clip point of the waveform at VIDEO OUT becomes $770 \pm 5 \text{ mV}$ as shown in Fig. 12-1. |
| | |  | | |  <p>Fig. 13-1</p> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|-------------------------|--|---------------------------------|--|---|
| 14. | AGC Adjustment | | | | |
| a. | AGC SET Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | VIDEO OUT AGC APACON R139 | R634 (AGC SET) AGC SET R634 | <p>1. Adjust the iris control knob (lens side) so that the VIDEO OUT level is 490 mV (70 IRE).</p>  <p>490 mV</p> <p>Fig. 14-1</p> |
| b. | AGC Depender Adjustment | Oscilloscope Gray scale pattern | VIDEO OUT | R138 (AGC Y SET UP) R139 (AGC APA-CON) R140 (AGC V.CON-TOUR) | <p>2. Set the AGC switch to ON and adjust R634 (AGC SET) so that the VIDEO OUT level is 510 ± 10 mV.</p> <p>● Close the iris. AGC switch: ON</p> <p>1. Adjust R138 (AGC Y.SET UP) so that the SET UP is 107 mV (15 IRE).</p>  <p>107mV</p> <p>Fig. 14-2</p> <p>● Remove the lens cap.</p> <p>2. Adjust the iris control knob (lens side) so that the VIDEO OUT level is 357 mV (50 IRE).</p> <p>3. Adjust R139 (AGC APACON) so that the over shoot (H-rate) of the VIDEO OUT waveform is aligned with the top of the white peak waveform.</p>  <p>Over shoot</p> <p>Fig. 14-3</p> <p>4. Adjust R140 (AGC V.CONTOUR) so that the over shoot (V-rate) of the VIDEO OUT waveform is aligned with the top of the white peak waveform.</p>  <p>Over shoot</p> <p>Fig. 14-4</p> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|-----------------------|---|------------|------------------|--|
| 15. | APACON Adjustment | Oscilloscope (H-rate) 10:1 Gray scale pattern | VIDEO OUT | R17 (APACON) | <p>1. Adjust the iris control knob (lens side) so that the VIDEO OUT output is 560 mV (80 IRE).</p> <p>● At that time, the focus should be adjusted precisely. If the focus is not aligned, the overshoot cannot be measured correctly.</p> <p>2. Adjust R17 (APACON) so that overshoot is $107 \pm 35\text{mV}$ (15 ± 5 IRE) as shown in Fig. 15-1.</p> |
| | |  | | |  |
| | | | | | Fig. 15-1 |
| 16. | SYNC LEVEL Adjustment | Oscilloscope (H-rate) 10:1 | VIDEO OUT | R85 (SYNC.LEVEL) | <p>1. Close the iris by applying the lens cap. Adjust R85 (SYNC. LEVEL) so that the sync level is set at 0.3 Vp-p as shown in Fig. 16-1.</p> |
| | |  | | |  |
| | | | | | Fig. 16-1 |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|---|------------------------|--------------------------------|------------|-------------------------------|---|
| 17. | BURST LEVEL Adjustment | Vectorscope | VIDEO OUT | R21 (BURST GAIN) R22 (HUE) | <p>● Close the iris by applying the lens cap.</p> <ol style="list-style-type: none"> Adjust R22 (HUE) so that the BURST becomes PAL BURST POSITION. Adjust R21 (BURST GAIN) so that the BURST LEVEL is set at the 75% shown in Fig. 17-1. |
| <div style="display: flex; justify-content: space-around; align-items: center;">  <p>Fig. 17-1</p> </div> <div style="display: flex; justify-content: center; align-items: center; margin-top: 20px;">  <div style="margin-left: 20px;"> <p>Notes</p> <ol style="list-style-type: none"> The BURST POSITION adjustment can only be performed with a vectorscope. A rough adjustment of BURST GAIN is possible also with an oscilloscope. </div> </div> <div style="text-align: center; margin-top: 20px;">  <p>Fig. 17-2</p> </div> | | | | | |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|----------------------------------|--|------------|--------------------------------|---|
| 18. | IN-DOOR WHITE BALANCE Adjustment | Oscilloscope (H-rate) (10:1) Gray scale pattern | VIDEO OUT | R679 (B GAIN) R680 (R GAIN) | <ul style="list-style-type: none"> ● Perform this adjustment only when the white balance is found to be abnormal when the gray scale is displayed. <div>Procedures of adjustment with oscilloscope</div> <ol style="list-style-type: none"> 1. Adjust R680 (R GAIN) and R679 (B GAIN) by turns so that the carrier becomes minimum. (See Fig. 18-1.)  <div>Fig. 18-1</div> |
| | | Vectorscope Gray scale pattern | VIDEO OUT | R679 (B GAIN) R680 (R GAIN) | <div>Procedures of adjustment with vector scale</div> <ul style="list-style-type: none"> ● Adjustment can be easily made near the zero point by increasing the gain of the vectors cope. <ol style="list-style-type: none"> 1. Adjust R680 (R GAIN) and R679 (B GAIN) by turns so that the carriers set minimum and at the center of the vectorscope as shown in Fig. 18-2.  <div>Fig. 18-2</div> |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|---------------------------------|---|------------|--|---|
| 19. | COLOUR RE-PRODUCTION Adjustment | Vectorscope Colour bar pattern (CC-2T) | VIDEO OUT | R128 (R-Y GAIN) R129 (B-Y GAIN) R681 (G MIX) | <ol style="list-style-type: none"> 1. Display the colour bar pattern, and see that the white portion is set at 0.7 V_{Wb-Pb}. 2. Adjust R128 (R-Y GAIN) so that the red portion is put to (A) as shown in Fig. 19-1. Adjust R129 (B-Y GAIN) so that the yellow level is put to (B) as shown in Fig. 19-1. |
| | | Monitor TV | | | |





Fig. 19-1

NOTE: If no vectorscope is available, adjust R129 (B-Y GAIN) and R128 (R-Y GAIN) so that optimum colour reproducibility is obtained, while observing the colour bar pattern displayed on the monitor TV.

3. Adjust R681 (G MIX) and minimize the crawling displayed on the monitor TV. (Like a state of non interless)






| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|---|---|--|---|--|
| 20. | OUT DOOR WHITE BALANCE Adjustment | Oscilloscope (H-rate 10:1) Gray scale Pattern 80C + CC10C + CC10B Filter or equivalent, 1 filter | VIDEO OUT  | R657 (OUT-B) R661 (OUT-R) | <u>Procedures of adjustment with oscilloscope</u> 1. Mount Filter on the lens, and set the white balance SW to "☀" (OUT-DOOR). 2. Adjust R657 (OUT-B) and R661 (OUT-R) by turns so that the carrier for the waveform may be minimized. (See Fig. 20-1.) |
| | | Vectorscope  | VIDEO OUT  | R657 (OUT-B) R661 (OUT-R) | <u>Procedures of adjustment with the vectorscope</u> 1. Attach the on the lens, and set the white balance control to "☀" (OUT-DOOR) position. 2. Alternately adjust the R657 (OUT-B) and R661 (OUT-R) so that the carrier is located at the center of the vectorscope. |
| 21. | IRIS VIDEO LEVEL IRIS SYNC LEVEL | Oscilloscope Gray scale Pattern | Pin ② (Video) of Rear IRIS terminal  | R603 (IRIS VIDEO LEVEL) R651 (IRIS SYNC LEVEL) | 1. Measure voltage at pin ② of rear IRIS terminal and adjust R603 (IRIS VIDEO LEVEL) so that the voltage at pin ② is 700 mV. 2. Adjust R651 (IRIS SYNC LEVEL) so that the SYNC level is 300 mV. |



Fig. 20-1

Fig. 20-2



| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|-----------------------|--|------------|---------------------------|---|
| 22. | BACK FOCUS Adjustment | Monitor TV Siemens chart, resolution chart, or subject with clear white and black stripes | VIDEO OUT | LOCK SCREW FOCUS SCREW | <ul style="list-style-type: none"> It is not necessary to remove the cover before this adjustment. Under a relatively dark illumination, open the lens iris. <ol style="list-style-type: none"> Place the Siemens chart at a position 3 meter or more apart from the camera. (Place the chart as far as possible from the camera.) Set the camera zooming to the telephoto end and focus the chart. After focusing, slowly turn the zoom ring toward the wide-angle end and make sure that the object is always focused correctly. If focusing varies, loosen the lock screw and turn the focus screw for optimum focusing. Repeat steps 2 and 3 until focusing becomes always optimum. When the optimum backfocusing is obtained, tighten the lock screw. |
| 23. | FINAL CHECK | Vectorscope Oscilloscope Colour bar pattern Gray scale pattern Coloured subject etc. | VIDEO OUT | | <ol style="list-style-type: none"> Shoot the colour bar pattern in the auto iris mode and make sure that the colour carriers are located as indicated in Fig. 23-1. (only for the lens with auto iris function) Manipulate the white balance switch, and other switches to see that they work normally. Shoot the gray scale pattern and check γ, WHITE BALANCE, Y SETUP, etc. at VIDEO OUT. Shoot an appropriate subject and check colors, reproducibility and other functions of the camera. If results of check are unsatisfactory, repeat the steps for adjustment as appropriate. |











Fig. 23-1

4. ADJUSTMENTS OF RGB CIRCUIT


Proceed to this adjustment only after having completed the adjustments of the power supply, SSG and signal system.

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|------------------------------|--|---|------------------------------------|---|
| 1. | Chroma Difference Adjustment | Oscilloscope (H-rate) (10:1) Colorbar Pattern | VIDEO OUT TP-1 R-Y (Main Board C Block) TP-2 B-Y (Main Board C Block) | Y-R (MTX) Y-B (MTX) | <ul style="list-style-type: none"> Adjust the IRIS control (on the lens) to set the level of the VIDEO OUT waveform at 0.7 VWD-PD. <ol style="list-style-type: none"> While observing the waveforms at TP-1 and at R-Y in the C Block of the Main Board, adjust the Y-R (MTX) potentiometer so that the level relation at TP-1 is equal to the level ratio at R-Y in the C Block.  <p>Align a : b with the ratio at R-Y in the C Block.</p> <p>Fig. 4-1</p> <ol style="list-style-type: none"> While observing the waveforms at TP-2 and at B-Y in the C Block of the Main Board, adjust the Y-B (MTX) potentiometer so that the level relation at TP-2 is equal to the level ratio at B-Y in the C Block.  <p>Align a : b with the ratio at B-Y in the C Block.</p> <p>Fig. 4-2</p> |






| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|--|--|--|--|--|
| 2. | Chroma Difference Signal Gain Adjustment | Oscilloscope (H-rate) (10:1) (DC range) Colourbar Pattern | VIDEO OUT R-OUT B-OUT G-OUT | Y-R (GAIN) Y-B (GAIN) Y-B (MTX) Y-G (MTX) | <ul style="list-style-type: none"> Adjust the IRIS control (on the lens) to set the level of the VIDEO OUT waveform at 0.7 VWD-PD. <ol style="list-style-type: none"> While measuring R-OUT, adjust the Y-R (GAIN) potentiometer to align the level of Mg with the W level.  <p>Fig. 4-2 (a)</p> <ol style="list-style-type: none"> Turn the Y-B (GAIN) potentiometer clockwise until just before the waveform is disordered. Adjust the Y-B (MTX) potentiometer to set the level of Mg at approx. 83% of Cy.  <p>Fig. 4-2 (b)</p> <ol style="list-style-type: none"> While measuring G-OUT, adjust the Y-G (MTX) potentiometer to set the level of G at approx. 83% of YL.  <p>Fig. 4-2 (c)</p> |

■ R/G/B, REF/VIDEO OUT connectors
For the R/G/B, ref. and video signal outputs.



| Pin No. | 1 | 2 | 3 | 4 |
|---------------|------------|---------------------------|-------|-------|
| Terminal Name | GND (MAIN) | GND (COMP) (VIDEO) (SYNC) | R-OUT | G-OUT |

| 5 | 6 | 7 | 8 | 9 |
|-------|-----------------|----------------|-----|-----|
| B-OUT | COMP. VIDEO OUT | COMP. SYNC OUT | GND | GND |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|---------------------------|--|------------|------------------------|--|
| 3. | RGB Gain Setup Adjustment | Oscilloscope (H-rate 10:1) Gray scale pattern | R-OUT | R (GAIN) R (SET UP) | <ul style="list-style-type: none"> ● AGC Switch OFF. ● Adjust the IRIS control (on the lens) to set the level of the VIDEO OUT waveform at 700 mV_{PD-WP}. <ol style="list-style-type: none"> 1. While measuring R-OUT, adjust the R (GAIN) potentiometer to set the amplitude from black to white to 650 mV. (Fig. 4-3 (a))  <p>Fig. 4-3 (a)</p> <ol style="list-style-type: none"> 2. Cap the lens to block the light incident to the iris. 3. Adjust the R (SET UP) potentiometer to make the setup level waveform flat (0 V) as shown in Fig. 4-3 (b).  <p>Fig. 4-3 (b)</p> <ol style="list-style-type: none"> 4. Remove the cap from the lens and check that the voltage difference between the blanking and white-peak levels is 700 mV. If not, adjust the R (GAIN) potentiometer for 700 mV and check the setup level again.  <p>Fig. 4-3 (c)</p> |
| | | | B-OUT | B (GAIN) B (SET UP) | Use the same procedure as the R-OUT adjustment. |
| | | | G-OUT | G (GAIN) G (SET UP) | Use the same procedure as the R-OUT adjustment. NOTE: Adjust so that each RGB output becomes the same gain. |

| No. | Item | Measuring instrument & pattern | Test point | Adjustment part | Description |
|-----|--------------|--------------------------------|------------|-----------------|---|
| 4. | Confirmation | RGB monitor | | | <ul style="list-style-type: none">● If an RGB monitor is available, confirm the adjustment result with the following procedure. <ol style="list-style-type: none">1. Compare the RGB output and VIDEO output to check that they have similar hues.2. When the hues are different noticeably, perform the adjustments of the RGB circuit again. |

3. PARTS LIST

IMPORTANT SAFETY NOTICE:

Components identified by the \triangle symbol in this parts information have special characteristics for safety.

These critical safety components are designed to "fail safe" under abnormal conditions. The failure of any one component often causes stress in other components which could lead to smoke or fire or other hazards. Because of this, components are selected and tested under actual fault conditions to ensure safe operation. Replacement with anything other than the identical JVC part may present a hazard.

NOTE 1 SUPPLY OF PARTS WITHOUT PARTS NO.

The parts indicated with — in the Part No. column will not be supplied.

NOTE 2 SUPPLY OF CH MG R AND CH C CAP.

Chip Metal Glaze Resistor (CH MG R) and Chip Ceramic Capacitor (CH C Cap.) will not be supplied as follows, and are not generally described in the Printed Circuit Board parts list.

| Chip Metal Glaze Resistor (CH MG R) | | | Chip Ceramic Capacitor (CH C Cap.) | | |
|-------------------------------------|-------------|-----------|------------------------------------|---------------|-----------|
| Parts Number | Rated Power | Tolerance | Parts Number | Rated Voltage | Tolerance |
| QRS148J- | 1/4W | J | QCS81HJ- | 50V | J |
| QRSA08J- | 1/10W | J | QCT81CH- | 50V | J |
| QRSA08G- | 1/10W | G | QCT81UJ- | 50V | J |
| | | | QCF81HZ- | 50V | Z |
| | | | QCY81HK- | 50V | K |
| | | | QCY81EK- | 25V | K |
| | | | QCF81EZ- | 25V | Z |

NOTE 3 DECODING OF RESISTOR, CAPACITOR AND TOLERANCE

| RESISTOR All resistance values in ohms K: 1000 M: 1000000 | | CAPACITOR Capacitance values in pF or in μ F | | TOLERANCE | |
|---|--|---|--|--------------|----------|
| C R | Carbon Resistor | BP E Cap. | Bi-Polar (or Non-Polar) Electrolytic Capacitor | F $\pm 1\%$ | H +50 % |
| CH VR | Chip Variable Resistor | C Cap. | Ceramic Capacitor | G $\pm 2\%$ | -10 % |
| CMF R | Coating Metal Film Resistor | CH Tan. E | Chip Tantalum Electrolytic Capacitor | J $\pm 5\%$ | P +100 % |
| Comp. R | Composition Resistor | Cap. | Capacitor | K $\pm 10\%$ | -0 % |
| F R | Fusible Resistor | E Cap. | Electrolytic Capacitor | M $\pm 20\%$ | R +30 % |
| HV R | High Voltage Resistor | M Cap. | Mylar Capacitor | N $\pm 30\%$ | -10 % |
| LPTC R | Linear Positive Temperature Coefficient Resistor | MM Cap. | Metalized Mylar Capacitor | | Z +80 % |
| MF R | Metal Film Resistor | MP Cap. | Metalized Polystyrol Capacitor | | -20 % |
| MG R | Metal Glaze Resistor | MPP Cap. | Metalized PP Capacitor | | |
| OM R | Oxide Metal Film Resistor | PP Cap. | Polypropylene Capacitor | | |
| P R | Plate Resistor | PS Cap. | Polystyrol Capacitor | | |
| UNF R | Nonflammable Resistor | Tan. Cap. | Tantalum Capacitor | | |
| V R | Variable Resistor | CH AL BP | Chip Aluminum Bi-Polar Capacitor | | |
| | | Cap. | Capacitor | | |
| | | CH AL BP E | Chip Aluminum Bi-Polar Electrolytic Capacitor | | |
| | | Cap. | Capacitor | | |
| | | CH AL E Cap. | Chip Aluminum Electrolytic Capacitor | | |

NOTE 4 MARKING FOR THE PARTS THAT ARE STATIC SENSITIVE

The parts with the SS or S marking, shown below, are susceptible to static electricity. Therefore, care should be taken when servicing them.

Be particularly very careful with the parts having the SS marking.

S : Those parts that need care are already installed; perform normal servicing for ass'y.


SS : Be very careful.

Unmarked : Normal servicing

NOTE 5 MARKING FOR THE PARTS THAT NEED CARE WHEN TRANSPORTING OR STORING THEM

When transporting or storing them, avoid strong sunlight, dust, dirt, cracking, shortened life etc. These parts are indicated by a SK marking.

PACKING






PACKING PARTS LIST

| | | | | | | |
|---|---|---|---|--|--|--|
| M | 2 | M | M | | | |
|---|---|---|---|--|--|--|

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|------------|--------------|--------------|---------|
| 1 | TK-870E-1B-A | CAMERA BODY | TK-870E |
| 2 | CP20245-A0A | INST BOOK | |
| 4 | | CUSHION | |
| 5 | CP30004-031 | POLY. BAG | |
| 6 | CP20228-022 | PACKING CASE | |
| 8 | CE41155-001 | IRIS PLUG | |
| 10 | VC-450-2E | CABLE | |
| 11 | CP40190-001 | SLEEVE | |

■ EXPLODED VIEW





■ SYSTEM ASSEMBLY REPLACEMENT PARTS LIST

M1 MIM

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|---------------|-----------------|------------------|-------------------|
| 1 | | MAIN BOARD | CAW-1520A S. SK |
| 2 | CAW-A012A | IMAGER BOARD | S. SK |
| 3 | CAW-8511A | GEN-LOCK BOARD | S. SK |
| 4 | CAW-4511A | RGB BOARD | S. SK |
| 5 | SPSK2040R | MINI SCREW | (×2) |
| 6 | CM21094-003-M0 | FRONT COVER | |
| 7 | SPSK2040R | MINI SCREW | (×4) |
| 8 | CM21095-B01-M0 | REAR COVER | |
| 9 | CM32199-008 | REAR PLATE | |
| 10 | SPSK2040R | MINI SCREW | (×4) |
| 11 | CM21097-00A | TOP COVER ASSY | |
| 12 | SSEP2606 | SCREW | (×2) |
| 13 | CM21098-001 | BOTTOM COVER | |
| 14 | SSEP2606 | SCREW | (×2) |
| 15 | CM21096-B0A | TRI-BASE ASSY | |
| 17 | CM32196-003 (R) | ROLL N LABEL | |
| 18 | SHSP2606R | SCREW | (×4) |
| 19 | CM32188-A01 | TOP PLATE | |
| 21 | SHSP2606R | SCREW | (×4) |
| 22 | ICX021-K | CCD IMAGER | SS. SK |
| 23 | CM31968-A01 | IMAGER HOLDER | |
| 24 | CM44002-001 | MINI SCREW | (×2) |
| 25 | CM43691-001 | I RUBBER | SK |
| 26 | CM32190-B0A | ADJUSTRING ASSY | |
| 27 | SPSK2050M | MINI SCREW | (×2) |
| 28 | CE41085-00B | L. P. FILTER | SK |
| 29 | CM44177-001 | FILTER HOLDER | |
| 30 | SSSK2040M | MINI SCREW | (×2) |
| 31 | CM32189-A02 | C MOUNT | |
| 32 | CM43994-001 | ADJUST SPRING | (×4) |
| 33 | CM43995-001 | ADJUST ARM | |
| 34 | CM43991-001 | SHAFT | |
| 35 | REE2000 | E RING | (×2) |
| 36 | CM32191-00A | ADJUST BKT | |
| 37 | SDSP2604Z | SCREW | (×2) |
| 38 | CM43993-002 | ECCENTRIC ROD | |
| 39 | SPSX2608Z | PM SCREW | |
| 40 | CM43996-001 | LOCK PLATE | |
| 45 | CM32193-001 | FRONT BKT | |
| 46 | SPSK2040R | MINI SCREW | (×2) |
| 47 | CM32195-001 | BTM BEAM | |
| 48 | CM32195-002 | BTM BEAM | |
| 49 | SPSK2040R | MINI SCREW | (×4) |
| 50 | CM21099-B0F | TERMINAL ASSY | in No. 50-1-50-17 |
| 50-10 | QVAA004-CB54A | V R | TINT |
| 50-16 | CE41255-001 | DIN SOCKET | |
| 50-17 | CH40326-009SN | D SUB 9S | |
| 51 | CM32194-A01 | TOP BEAM | |
| 52 | SPSK2040R | MINI SCREW | (×4) |
| 56 | CM40016-001 | DUST COVER | |
| 61 | SPSP2604Z | SCREW | |
| 62 | CM44152-001 | CAUTION LABEL | |
| 63 | C41708 | LABEL | |
| 64 | NNS2000Z | NUT | (×2) |
| 66 | SPSK2040R | MINI SCREW | (×2) |
| 67 | CM44161-A01 | PHASE LABEL | |
| 68 | CM44221-001 | PHASE ADJ. LABEL | |
| 71 | SPSK2040R | MINI SCREW | (×4) |
| 72 | CM32184-B01 | SHIELD CASE-FR | |
| 81 | CM44314-001 | EARTH SPRING | |

■ PRINTED CIRCUIT BOARD PARTS LIST

1 0

1. CAW-1520A MAIN BOARD

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|------------|----------------|-----------------|----------------------|
| VARIABLE R | | | |
| R1017 | CE40150-103WA | CH V R | 10kΩ APACON |
| R1019 | CE40412-103WYA | CH V R | 10kΩ CAR BAL 90° |
| R1020 | CE40412-103WYA | CH V R | 10kΩ CAR BAL 0° |
| R1021 | CE40412-103WYA | CH V R | 10kΩ BURST GAIN |
| R1022 | CE40412-103WYA | CH V R | 10kΩ HUE |
| R1025 | CE40412-103WYA | CH V R | 10kΩ Y SET UP |
| R1026 | CE40150-103WA | CH V R | 10kΩ W CLIP |
| R1029 | CE40150-103WA | CH V R | 10kΩ Y GAIN |
| R1085 | CE40150-472WA | CH V R | 4.7kΩ SYNC. L |
| R1122 | CE40150-103WA | CH V R | 10kΩ R2/B2 GAIN |
| R1123 | CE40150-103WA | CH V R | 10kΩ G2 GAIN |
| R1124 | CE40150-103WA | CH V R | 10kΩ R1/B1 GAIN |
| R1125 | CE40150-103WA | CH V R | 10kΩ G1 GAIN |
| R1127 | CE40412-103WYA | CH V R | 10kΩ MPX-DC |
| R1128 | CE40150-103WA | CH V R | 10kΩ R-Y GAIN |
| R1129 | CE40150-103WA | CH V R | 10kΩ B-Y GAIN |
| R1138 | CE40150-474WA | CH V R | 470kΩ AGC Y. SET UP |
| R1139 | CE40150-104WA | CH V R | 100kΩ AGC APACON |
| R1140 | CE40150-474WA | CH V R | 470kΩ AGC V. CONTOUR |
| R1503 | CE40848-472YA | CH V R | 4.7kΩ 8.5V ADJ |
| R1603 | CE40412-103XYA | CH V R | 10kΩ IRIS VIDEO LE |
| R1634 | CE40150-331XA | CH V R | 330 Ω AGC SET |
| R1651 | CE40150-103XA | CH V R | 10kΩ IRIS SYNC. L |
| R1655 | CE40150-223XA | CH V R | 22kΩ IN-R |
| R1657 | CE40150-223XA | CH V R | 22kΩ OUT-B |
| R1658 | CE40150-223XA | CH V R | 22kΩ IN-B |
| R1661 | CE40150-223XA | CH V R | 22kΩ OUT-R |
| R1678 | CE40150-103XA | CH V R | 10kΩ AGC MAX. G |
| R1679 | CE40150-103XA | CH V R | 10kΩ B GAIN |
| R1680 | CE40150-103XA | CH V R | 10kΩ R GAIN |
| R1681 | CE40412-103XYA | CH V R | 10kΩ G MIX |
| R1682 | CE40412-103XYA | CH V R | 10kΩ R OFF SET |
| R1683 | CE40412-103XYA | CH V R | 10kΩ B OFF SET |
| R1684 | CE40150-103XA | CH V R | 10kΩ γ SET |
| R1685 | CE40150-223XA | CH V R | 22kΩ Y. KNEE |
| R1687 | CE40150-103XA | CH V R | 10kΩ G GAIN |
| R1707 | CE40150-223XA | CH V R | 22kΩ PED SET |
| RESISTOR | | | |
| R1143 | QRD161J-683 | C R | 68kΩ 1/6W J |
| R1144 | QRD161J-333Y | C R | 33kΩ 1/6W J |
| R1146 | QRD161J-821 | C R | 820 Ω 1/6W J |
| R1316 | QRD161J-271 | C R | 270 Ω 1/6W J |
| R1403 | QRD161J-103 | C R | 10kΩ 1/6W J |
| R1404 | QRD161J-473 | C R | 47kΩ 1/6W J |
| R1517 | QRD161J-1R5 | C R | |
| R1612 | QRD161J-473 | C R | 47kΩ 1/6W J |
| CAPACITOR | | | |
| C1003 | NEA11CM-106RZ | CHIP AL E CAP. | 10μF 16V M |
| C1008 | NEA11CM-106RZ | CHIP AL E CAP. | 10μF 16V M |
| C1010 | NEA11EM-336RP | CHIP AL E CAP. | 33μF 25V M |
| C1011 | NEA11CM-106RZ | CHIP AL E CAP. | 10μF 16V M |
| C1012 | NEA11CM-106RZ | CHIP AL E CAP. | 10μF 16V M |
| C1014 | NEE21CM-105RS | CHIP TAN E CAP. | 1μF 16V M |
| C1017 | NEE11CM-106RU | CHIP TAN E CAP. | 10μF 16V M |
| C1025 | QAT3110-300A | TRIMMER CAP | |
| C1026 | NEE21CM-105RS | CHIP TAN E CAP. | 1μF 16V M |
| C1028 | NEE11VM-105RZ | CHIP TAN E CAP. | 1μF 35V M |
| C1031 | NEE11CM-106RU | CHIP TAN E CAP. | 10μF 16V M |

| SYMBOL NO. | PART NO. | PART NAME | REMARKS | | |
|---------------|---------------|-----------------|--------------|------|---|
| CAPACITOR | | | | | |
| C1033 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1036 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1037 | NEE11CM-106RU | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1039 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1120 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F | 16V | M |
| C1202 | QEPA1HM-105M | BP E CAP. | 1 μ F | 50V | M |
| C1301 | NEE11CM-226RZ | CHIP TAN E CAP. | 22 μ F | 16V | M |
| C1304 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1311 | NEE11AM-336RZ | CHIP TAN E CAP. | 33 μ F | 10V | M |
| C1315 | NEE11CM-106RU | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1317 | QEE41CK-336M | TAN. CAP. | 33 μ F | 16V | K |
| C1318 | QEE41CK-336M | TAN. CAP. | 33 μ F | 16V | K |
| C1320 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1323 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1330 | NEE11CM-226RZ | CHIP TAN E CAP. | 22 μ F | 16V | M |
| C1336 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1337 | QFV41HJ-104M | TF CAP. | 0.1 μ F | 50V | J |
| C1340 | QCS11HJ-330 | C CAP. | 33pF | 50V | J |
| C1402 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1403 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1404 | QAT3110-300A | TRIMMER CAP | | | |
| C1406 | QEE51AK-336M | TAN. CAP. | 33 μ F | 10V | K |
| C1416 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1501 | NEA11CM-476RP | CHIP AL E CAP. | 47 μ F | 16V | M |
| C1507 | NEA11CM-476RP | CHIP AL E CAP. | 47 μ F | 16V | M |
| C1511 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1512 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F | 16V | M |
| C1513 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F | 16V | M |
| C1514 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F | 16V | M |
| C1515 | QETB1CM-477 | E CAP. | 470 μ F | 16V | M |
| C1516 | QET41VR-107 | E CAP. | 100 μ F | 35V | R |
| C1517 | QETA1AM-477 | E CAP. | 470 μ F | 10V | M |
| C1603 | NEE11VM-474RZ | CHIP TAN E CAP. | 0.47 μ F | 35V | M |
| C1604 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1607 | NEE11CM-225RZ | CHIP TAN E CAP. | 2.2 μ F | 16V | M |
| C1608 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1612 | QEPA1HM-105M | BP E CAP. | 1 μ F | 50V | M |
| C1621 | NEE11AM-336RU | CHIP TAN E CAP. | 33 μ F | 10V | M |
| C1622 | NEE11AM-336RZ | CHIP TAN E CAP. | 33 μ F | 10V | M |
| C1623 | NEE11CM-106RU | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1624 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F | 16V | M |
| C1625 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1628 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F | 16V | M |
| C1630 | NEA10JM-226RZ | CHIP AL E CAP. | 22 μ F | 6.3V | M |
| C1705 | QCY41HK-102A | C CAP. | 1000pF | 50V | K |
| TRANSFORMER | | | | | |
| T1001 | CE41090-00AY | REFLOW TRANS | | | |
| T1002 | CE41089-00AY | REFLOW TRANS | | | |
| T1004 | CE41121-A0AY | REFLOW TRANS | | | |
| T1005 | CE41211-00AY | B. PASS TRANSF | | | |
| T1101 | CE41120-00AY | REFLOW TRANS | | | |
| T1102 | CE41120-00AY | REFLOW TRANS | | | |
| COIL | | | | | |
| L1001 | CE41131-220Y | CHIP INDUCTOR | | | |
| L1502 | CJ39509-024 | HETER CHOKE | | | |

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|------------|-------------------|------------------|---------|
| DIODE | | | |
| D1002 | MA151A-W | CHIP DIODE | |
| D1003 | 1SV69 | VARICAP DIODE | |
| D1004 | MA151A-X | CHIP DIODE | |
| D1006 | MA151K-X | CHIP DIODE | |
| D1009 | 1S2473H | SI. DIODE | |
| D1010 | 1S2473H | SI. DIODE | |
| D1121 | MA157-X | CHIP DIODE | |
| D1301 | MA151WA-W | CHIP DIODE | |
| D1303 | 1SV68 | VARICAP DIODE | |
| D1304 | MA151WA-W | CHIP DIODE | |
| D1502 | MA3120 (L-II) -W | CHIP ZENER DIODE | |
| D1601 | MA151WA-W | CHIP DIODE | |
| D1602 | MA151WA-X | CHIP DIODE | |
| D1603 | MA151WK-W | CHIP DIODE | |
| D1604 | MA151K-W | CHIP DIODE | |
| D1606 | MA3120 (L-II) -W | CHIP ZENER DIODE | |
| D1610 | MA151A-W | CHIP DIODE | |
| D1705 | MA151K-W | CHIP DIODE | |
| TRANSISTOR | | | |
| Q1001 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1002 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1003 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1004 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1007 | 2SC2404 (D) -X | CHIP TRANSISTOR | |
| Q1011 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1012 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q1013 | 2SB709 (P-R) -X | CHIP TRANSISTOR | |
| Q1015 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1016 | 2SD1030 (R) -W | CHIP TRANSISTOR | |
| Q1020 | 2SC2259 | SI. TRANSISTOR | |
| Q1021 | 2SC2259 | SI. TRANSISTOR | |
| Q1022 | 2SC2259 | SI. TRANSISTOR | |
| Q1101 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q1102 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1103 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q1104 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q1201 | 2SC2778 (B, C) -W | SI. TRANSISTOR | |
| Q1202 | 2SC2778 (B, C) -W | SI. TRANSISTOR | |
| Q1301 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q1302 | 2SK94-X | CHIP F E T | SS. SK |
| Q1303 | 2SK94-W | CHIP F E T | SS. SK |
| Q1304 | 2SK94-X | CHIP F E T | SS. SK |
| Q1305 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1306 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1307 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1308 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1309 | 2SC2404 (D) -X | CHIP TRANSISTOR | |
| Q1501 | 2SB970 (Q-S) -X | CHIP TRANSISTOR | |
| Q1504 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1602 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1603 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1604 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q1605 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1606 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q1607 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q1608 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1609 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1610 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|---------------|-------------------|-----------------|---------|
| TRANSISTOR | | | |
| Q1611 | 2SB709 (P-R) -X | CHIP TRANSISTOR | |
| Q1614 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1615 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1616 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q1620 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q1621 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| IC | | | |
| IC1001 | CX20055 | I. C. | SS. SK |
| IC1002 | CX-7930A | I. C. | SS. SK |
| IC1201 | UPC358G-W | I. C. (M) | |
| IC1301 | CX23047B | I. C. | SS. SK |
| IC1302 | MB7052 | I. C. (M) | SS. SK |
| IC1303 | CX20053 | I. C. | SS. SK |
| IC1304 | CX20151 | I. C. | SS. SK |
| IC1305 | CX23039 | I. C. | SS. SK |
| IC1501 | UPC4558G-W | I. C. (M) | |
| IC1502 | UPC358G-W | I. C. (M) | |
| IC1602 | UPC4558G-W | I. C. (M) | |
| IC1604 | MN4053BS-X | I. C. (M) | SS. SK |
| IC1605 | UPD74HC04G-X | I. C. (M) | |
| OTHERS | | | |
| | CE41084-C0A | SW REGURATOR | |
| | CM32181-B01 | SHIELD CASE-FF | |
| | CM32182-A01 | SHIELD CASE-ER | |
| | CM32183-C01 | SHIELD CASE-FF | |
| | SPSH2040M | MINI SCREW | (x2) |
| | CM43967-001 | REG. SPACER | |
| | CM32185-A01 | HEAT SINK | |
| | SPSH2040M | MINI SCREW | (x2) |
| | SPSP2608Z | SCREW | |
| CP1301 | ICP-N15 | IC PROTECTOR | |
| SC1301 | CE41156 | IRIS SOCKET | |
| SW1301 | QSS1B23-C01 | SLIDE SWITCH | |
| SW1601 | QSS1A12-C02 | SLIDE SWITCH | |
| X1002 | CE40770-00B | 17HMZ CRYSTAL | |
| X1301 | CE41212-001 | 28.375MHZ X TAL | |

2. CAW-A012A IMAGER BOARD

A 2

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|------------|-------------------|------------------|------------------|
| CAPACITOR | | | |
| CA002 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA004 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA008 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA010 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA011 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA012 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA013 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA014 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| CA015 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| CA016 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA017 | NEE21VM-105RS | CHIP TAN E CAP. | 1 μ F 35V M |
| CA018 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA021 | NEE21VM-105RY | CHIP TAN E CAP. | 1 μ F 35V M |
| CA022 | NEE21VM-105RY | CHIP TAN E CAP. | 1 μ F 35V M |
| CA023 | NEE21VM-105RY | CHIP TAN E CAP. | 1 μ F 35V M |
| CA024 | NEE21VM-105RY | CHIP TAN E CAP. | 1 μ F 35V M |
| CA025 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F 16V M |
| CA026 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F 16V M |
| CA027 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F 16V M |
| CA031 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA032 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA033 | NEE21VM-105RS | CHIP TAN E CAP. | 1 μ F 35V M |
| CA034 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| CA035 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| CA036 | QKKB1EM-106GM | E CAP. | 10 μ F 25V M |
| CA037 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| CA041 | NEE11EM-106RU | CHIP TAN E CAP. | 10 μ F 25V M |
| DIODE | | | |
| DA001 | MA151WA-W | CHIP DIODE | |
| DA002 | MA151WA-W | CHIP DIODE | |
| DA003 | MA151WA-X | CHIP DIODE | |
| DA004 | MA151WA-X | CHIP DIODE | |
| DA005 | MA157-X | CHIP DIODE | |
| DA006 | MA151WA-X | CHIP DIODE | |
| DA007 | MA151WA-X | CHIP DIODE | |
| DA008 | MA3051-W | CHIP ZENER DIODE | |
| DA009 | 1S2473H | SI. DIODE | |
| TRANSISTOR | | | |
| QA001 | 2SC2778 (B. C) -X | CHIP TRANSISTOR | |
| QA002 | 2SC2778 (B. C) -X | CHIP TRANSISTOR | |
| QA003 | 2SC2778 (B. C) -X | CHIP TRANSISTOR | |
| QA004 | 2SC2778 (B. C) -X | CHIP TRANSISTOR | |
| QA005 | 2SC2404 (D) -X | CHIP TRANSISTOR | |
| IC | | | |
| ICA002 | CX20180 | I. C. | SS. SK |
| ICA003 | CXB0026M | I. C. | SS. SK |
| ICA004 | CXB0026M | I. C. | SS. SK |
| OTHERS | | | |
| | CE41122-010 | IC SOCKET | (\times 2) |
| | CM32179-001 | SHIELD CASE-1F | |
| | CM32180-A01 | SHIELD CASE-1R | |

3. CAW-4511A RGB & POWER BOARD

41

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|-------------|-------------------|-----------------|-------------------------|
| VARIABLE R | | | |
| R4008 | CE40624-222A | V. R | 2. 2K Ω Y-R GAIN |
| R4009 | CE40624-472A | V. R | 4. 7K Ω Y-R MAT. |
| R4018 | CE40624-103A | V. R | 10K Ω Y-B GAIN |
| R4019 | CE40624-472A | V. R | 4. 7K Ω Y-B GAIN |
| R4029 | CE40624-222A | V. R | 2. 2K Ω Y-G MAT. |
| R4046 | CE40624-103A | V. R | 10K Ω R SET UP |
| R4050 | CE40624-103A | V. R | 10K Ω B SET UP |
| R4054 | CE40624-103A | V. R | 10K Ω B SET UP |
| R4056 | CE40624-102A | V. R | 1K Ω R GAIN |
| R4057 | CE40624-102A | V. R | 1K Ω G GAIN |
| R4058 | CE40624-102A | V. R | 1K Ω B GAIN |
| CAPACITOR | | | |
| C4001 | NEE21CM-105RS | CHIP TAN E CAP. | 1 μ F 16V M |
| C4002 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| C4003 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| C4004 | NEE21CM-105RY | CHIP TAN E CAP. | 1 μ F 16V M |
| C4010 | NEA11CM-106RZ | CHIP AL E CAP. | 10 μ F 16V M |
| C4013 | NEE11CM-106RZ | CHIP TAN E CAP. | 10 μ F 16V M |
| C4014 | QETB1CM-477 | E CAP. | 470 μ F 16V M |
| C4016 | QETB1CM-477 | E CAP. | 470 μ F 16V M |
| TRANSFORMER | | | |
| T4001 | CE41282-00AY | REFLOW TRANS | |
| T4002 | CE41282-00AY | REFLOW TRANS | |
| COIL | | | |
| L4001 | CE40344-121YL | CHIP INDUCTOR | |
| DIODE | | | |
| D4001 | MA151K-X | CHIP DIODE | |
| D4002 | W06A | SI. DIODE | |
| TRANSISTOR | | | |
| Q4001 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4002 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q4003 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4004 | 2SC2778 (B, C) -W | SI. TRANSISTOR | |
| Q4005 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4006 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4007 | 2SB709 (P-R) -X | CHIP TRANSISTOR | |
| Q4008 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4009 | 2SC2778 (B, C) -X | CHIP TRANSISTOR | |
| Q4010 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4011 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4012 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4013 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4014 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4015 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4016 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4017 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4018 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q4023 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q4024 | 2SB709 (P-R) -X | CHIP TRANSISTOR | |
| Q4025 | 2SB709 (P-R) -X | CHIP TRANSISTOR | |
| Q4026 | 2SD1030 (R) -W | CHIP TRANSISTOR | |
| Q4027 | 2SD1030 (R) -X | CHIP TRANSISTOR | |
| Q4028 | 2SD1030 (R) -X | CHIP TRANSISTOR | |
| Q4029 | 2SD1030 (R) -W | CHIP TRANSISTOR | |
| Q4030 | 2SD1030 (R) -X | CHIP TRANSISTOR | |

CAW-4511A RGB & POWER BOARD

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|---------------|--------------|------------|---------|
| IC IC4001 | M51324P-X | I. C. | |
| OTHERS | CM44450-001 | FUSE LABEL | |
| | CM44450-002 | FUSE LABEL | |
| | A44594-002 | FUSE CLIP | (x4) |
| △ F4001 | QMF51E2-1R0S | FUSE | 1.0A |
| △ F4002 | QMF51E2-R40S | FUSE | 0.4A |

4. CAW-8511A GEN-LOCK BOARD

8 1

| SYMBOL NO. | PART NO. | PART NAME | REMARKS |
|------------|-------------------|-----------------|----------------|
| VARIABLE R | | | |
| R8148 | A76195-682 | V R | 6.8kΩ SC PHASE |
| R8151 | A76195-223 | V. R | 22kΩ H PHASE |
| RESISTOR | | | |
| R8186 | QRD161J-474 | C R | 470kΩ 1/6W J |
| R8190 | QRD161J-224 | C R | 220kΩ 1/6W J |
| CAPACITOR | | | |
| C8101 | NEE11VM-474RZ | CHIP TAN E CAP. | 0.47μF 35V M |
| C8103 | NEE11CM-106RZ | CHIP TAN E CAP. | 10μF 16V M |
| C8105 | NEE11VM-474RZ | CHIP TAN E CAP. | 0.47μF 35V M |
| C8106 | NEE11CM-106RZ | CHIP TAN E CAP. | 10μF 16V M |
| C8107 | NEE21CM-105RY | CHIP TAN E CAP. | 1μF 16V M |
| C8116 | QFP31HJ-182S | PP CAP. | 1800pF 50V J |
| C8117 | QFP31HJ-681S | PP CAP. | 680pF 50V J |
| C8122 | NEE11CM-225RU | CHIP TAN E CAP. | 2.2μF 16V M |
| C8128 | QEN51HM-225 | BP E CAP. | 2.2μF 50V M |
| C8129 | NEE11CM-106RZ | CHIP TAN E CAP. | 10μF 16V M |
| C8130 | NEE11CM-106RZ | CHIP TAN E CAP. | 10μF 16V M |
| COIL | | | |
| L8005 | CE40344-220YL | CHIP INDUCTOR | 22μH |
| L8101 | CE40344-220YL | CHIP INDUCTOR | 22μH |
| L8102 | CE40344-820YL | CHIP INDUCTOR | 82μH |
| L8103 | CE40344-220YL | CHIP INDUCTOR | 22μH |
| DIODE | | | |
| D8001 | MA151WA-W | CHIP DIODE | |
| TRANSISTOR | | | |
| Q8101 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8102 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8103 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q8104 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q8105 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8106 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8107 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q8108 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8110 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8111 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8112 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8113 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8114 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8116 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8117 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8118 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8119 | 2SC2778 (B, C) -W | CHIP TRANSISTOR | |
| Q8120 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| Q8121 | 2SB709 (P-R) -W | CHIP TRANSISTOR | |
| IC | | | |
| IC8001 | TC4053BF-X | I. C. (M) | |
| IC8002 | TC4538BF-X | I. C. (M) | |
| IC8003 | MC14046BF-X | I. C. (H) | |
| IC8004 | AN610P | I. C. | SS, SK |
| IC8005 | UPC358G-W | I. C. (M) | |
| OTHERS | | | |
| SW8001 | QSS4B23-C01 | SLIDE SWITCH | |